

Quality Fasteners Specialist

No. 4, M.G.S. Complex, Benki Nawab Street, S.P. Road Cross, Bangalore 560002

8310165941 / 9008782885

sales@royalfastenersindia.com



An ISO 9001:2015 Certified Co


www.royalfastenersindia.com

# **BLIND RIVETS** A TECHNICAL GUIDE


## TECHNICAL CATALOGUE NUMBER: TECH0003

Also known as Break-Stem or Pop Rivets. They are called "Blind" Rivets because they can be installed from one side of the work. This allows product design to be simplified since only one side of the workpiece needs to be accessible.

# TERMS



## MATERIAL COMBINATIONS



Rivet body can be from Aluminium (Al), steel (ST) or Stainless Steel AISI 304 (A2), AISI 316 (A4). Corresponding mandrel options are as above.



Quality Fasteners Specialist

No. 4, M.G.S. Complex, Benki Nawab Street, S.P. Road Cross, Bangalore 560002

8310165941 / 9008782885

sales@royalfastenersindia.com




An ISO 9001:2015 Certified Co

www.royalfastenersindia.com

#### **BLIND RIVETS** A TECHNICAL GUIDE

## TECHNICAL CATALOGUE NUMBER: TECH0003

**BLIND RIVET INSTALLATION** 



HEAD STYLES – Various head styles are offered to accommodate different assembly needs.



The most popular is the Dome Head, whose lower profile head is approximately twice the diameter of the rivet body. This provides adequate bearing surface for nearly all applications.

Large Flange Head Rivet provides greater bearing surface for fastening soft or brittle facing materials.

Countersunk Head Rivet is for electric or electronic applications and in situations where a flush fixing is necessary.

## SELECTION GUIDELINES

- 1. The shear and tensile strength of the rivet selected and the number of rivets used in the application should be equal or exceed the joint strength requirements. Testing is recommended before final selection and use in the product.
- 2. The rivet body material should be compatible with the materials to be joined to resist any galvanic corrosion which may result in reduction of joint strength. If dissimilar materials are widely separated on the galvanic chart, it is advisable to separate them with a di-electric material such as paint or any other coating.
- 3. After determination of strength required by diameter and alloy, the total thickness of materials to be joined must be considered. Select the rivet grip range which includes the total thickness of the materials to be joined.



Quality Fasteners Specialist

No. 4, M.G.S. Complex, Benki Nawab Street, S.P. Road Cross, Bangalore 560002

8310165941 / 9008782885

sales@royalfastenersindia.com



An ISO 9001:2015 Certified Co

www.royalfastenersindia.com

# **BLIND RIVETS** A TECHNICAL GUIDE

## TECHNICAL CATALOGUE NUMBER: TECH0003

4. Recommended hole sizes listed for each rivet diameter should be followed closely. An under-sized hole will not allow insertion of the rivet body; whereas an oversize hole will reduce shear and tensile strengths and may cause improper rivet setting, all of which promote joint failure.

# DESIGN GUIDELINES

## 1. GAP FASTENING


Avoid riveting unsupported internal sections which may result in collapsing, dimpling or buckling of the material.

Select supported sections for best success.



## 2. PIVOT FASTENING

When the fastened part must rotate on the rivet, a "pivot-style" nose-piece on the rivet tool may be necessary to provide a small gap under the rivet head.



3. FASTENING IN A BLIND HOLE

Blind rivets may be set in a blind hole or milled slot. The success of this depends on the material of the parts to be riveted and the material of the rivet. Testing will be required.



Quality Fasteners Specialist

No. 4, M.G.S. Complex, Benki Nawab Street, S.P. Road Cross, Bangalore 560002

S 8310165941 / 9008782885

sales@royalfastenersindia.com




An ISO 9001:2015 Certified Co

www.royalfastenersindia.com

## **BLIND RIVETS** A TECHNICAL GUIDE


# TECHNICAL CATALOGUE NUMBER: TECH0003

(HP)



# 5. HARD TO SOFT MATERIALS

The following illustration is a guide for using standard blind rivets to fasten hard materials to soft materials. Other options are to use Groove Rivets or T-Lock Rivets.



## 6. EDGE DISTANCE

We recommend 2 times the rivet body diameter (D) or more from the centre of the rivet to the edge of the work piece to avoid material fracture.



# Royal Industrial Suppliers Quality Fasteners Specialist

No. 4, M.G.S. Complex, Benki Nawab Street, S.P. Road Cross, Bangalore 560002

8310165941 / 9008782885 

sales@royalfastenersindia.com



An ISO 9001:2015 Certified Co

www.royalfastenersindia.com

# **BLIND RIVETS A TECHNICAL GUIDE**

## **TECHNICAL CATALOGUE NUMBER: TECH0003**

